



"The Alternate Source"™

# replacement parts industries, inc.

CALL 800-221-9723 or 818-882-8611 • FAX 818-882-7028  
E-MAIL: techsupport@rpiparts.com • WEBSITE: www.rpiparts.com

## ADK033 VACUUM DRAIN KNOB SERVICE KIT INSTALLATION INSTRUCTIONS

1. Remove and disassemble the vacuum drain valve.
2. Clean and lubricate all parts using High Temp Lubricant (RPI Part #RPL090) prior to reassembly.
3. Refer to the illustration to reinstall parts.

