



replacement parts industries, inc.

"The Alternate Source"™

CALL 800-221-9723 or 818-882-8611 • FAX 818-882-7028

E-MAIL: techsupport@rpiparts.com • WEBSITE: www.rpiparts.com

CAM050 MOTOR ASSEMBLY WIRING INSTRUCTIONS

**RPI PART #CAM050
WIRE COLOR**

**TO CONNECTIONS
IN CERTRIFUGE**

BLACK	GOES TO	S3B COM
RED	GOES TO	S3A COM
BLUE	GOES TO	TB1 NO. 6
YELLOW	GOES TO	TB1 NO. 1
WHITE	GOES TO	S3B NO. (NORM. OPEN)

S3A is switch closest to motor. S3B is switch furthest from motor.

Note: As 12/97 wire colors on the RPI motor are the same as the OEM's wire colors.