



replacement parts industries, inc.

CALL 800-221-9723 or 818-882-8611 • FAX 818-882-7028

E-MAIL: techsupport@rpiparts.com • WEBSITE: www.rpiparts.com

PCH186 to fit OCM units with Serial No's 69564 and above PCH187 to fit OCR units with Serial No's 15050 and above WIRING HARNESS WIRING DIAGRAM INSTRUCTIONS

1. Remove power source (un-plug from wall).
2. Connect each quick connect per diagram below.
(Note: Each quick connect is labeled with a "QC" number (eg. QC1, QC2, QC3, etc.).)
3. Mount potentiometer to front panel.
4. Connect Molex plug to connector on control board.
5. Apply power.
6. Run cycle.
7. Calibrate as necessary.

