



PEL-CLEAN™

For use with
all Pelton & Crane® Sterilizers

To reorder, ask for:

RPI Part #PCC249

16 oz. Bottle

RPI Part #PCC250

(Case of 12) 16 oz. Bottles

PEL-CLEAN™ is a multi-purpose, slightly alkaline, mild solution developed to remove grease and grime from sterilizers. Used as directed PEL-CLEAN™ will also retard the accumulation of scale deposits. Always follow equipment manufacturer's instructions and recommended maintenance schedules. PEL-CLEAN™ is intended to be used in all Pelton & Crane® sterilizers.

To assist in the cleaning of sterilizers, RPI offers a complete cleaning kit that includes a variety of brushes, sponge, cleansing pad, and convenient carrying case. Ask for the **Cleaning Kit (RPI Part #RPK791)**.

To access the Material Safety Data Sheet, please refer to the RPI website www.rpiparts.com or call (800) 221-9723.

— 16 —
OUNCES

— 15 —

— 14 —

— 13 —

— 12 —

— 11 —

— 10 —

— 9 —

— 8 —

— 7 —

— 6 —

— 5 —

— 4 —

— 3 —

— 2 —

— 1 —



PEL-CLEAN™

Directions

1. Drain the water reservoir and remove any debris that might have accumulated.
2. Mix (64) ounces of distilled or demineralized water with (6) ounces of PEL-CLEAN™ and pour this solution into the water reservoir.
3. Run one normal cycle for unwrapped instruments, omitting the drying cycle. ***Never sterilize instruments during a cleaning cycle.***
4. When the cleaning cycle is complete, drain and rinse the reservoir until the water runs clear. Refill with clean distilled or demineralized water.
5. Run one normal cycle for unwrapped instruments, omitting the drying cycle. ***Never sterilize instruments during a cleaning cycle.***
6. Drain and rinse the reservoir until the water runs clear. Additional cleaning cycles may be required. Let the chamber cool to room temperature.
7. Remove all trays and racks. Using a clean lint-free cloth, wipe down the inside of the chamber. Be careful not to damage the heating element, sensors or filters that may be present. If filters are present, examine them and clean or replace as necessary.
8. Using a clean lint-free cloth, wipe down and clean all trays and racks. Carefully reinstall the trays and racks.
9. Remove the door gasket. Clean the door gasket and gasket groove. Examine the door gasket, and replace if necessary. Reinstall the door gasket.
10. Refill the water reservoir with clean distilled or demineralized water.
11. The sterilizer is ready for use.

CAUTION - Keep out of reach of children. Contains alkaline ingredients. **DO NOT** take internally. If ingested, seek medical attention immediately. May cause irritation to eyes and skin. **Contact with eyes:** Immediately flush with running water for 15 minutes. **Contact with skin:** Wash with soap and water, rinse with running water for 15 minutes. In case of inhalation that causes irritation, move person to fresh air immediately. If symptoms persist, seek medical attention immediately.

replacement parts industries, inc.

CALL (818) 882-8611 or (800) 221-9723 • FAX (818) 882-7028

E-MAIL order@rpiparts.com • WEBSITE rpiparts.com